BFM® fitting

Keeping You Connected















FROM THIS....





IEEICI II T	TO I	FIT	

PRUDUCI	DUILD	UP	IJJUEJ	

	Standard Hose Clamped Flexible Connectors	BFM™ System
HYGIENE	Product building up between the flexible connector and the side wall of the spigot	No crevices for product to get caught in.
SIZING	From inaccuracies in measuring on site through to production, it can be very difficult to get a perfect fit of a hose clamped connector.	PERFECT fit every time.
FITTING	Both the speed and accuracy of fitting hose clamps can vary widely and often clamps are not fitted correctly.	Can only fit in exactly the correct place, i.e. in or out.
EXPLOSION	In an over pressure situation hose clamps are normally always the weakest link and give up or let go long before the flexible connector would be due to rupture.	Only seals tighter under high pressures.
STANDARD SIZES	Current flexible connectors are made any size whatsoever, hence there are thousands of different sizes.	Set standard sizes in 50mm increments helps standardise stock holdings of spare parts.
HEALTH & SAFETY	When using screw drivers to tighten up hoseclips, damage is common to the flexible connector and even the installers hands.	Tool free connector changing, simply snap in with your hands.

To This....




ELIMINATES ALL PRODUCT BUILD UP

BFM® SPIGOTS


Patents and Registered Designs Applied For © 2006 All rights reserved






When welding the BFM™ Fittings to your equipment the
Application Length must be accurately measured.

Ø (Diameter)
100
125
150
200
250
300
350
400
450
500
550
600
650







In-line static
equipment
IG = CL — 10mm
(Minimum)

Off Set
equipment
IG = CL — 20mm
(Minimum)

Oscillating
equipment
IG = CL — 40mm
(Minimum)

CL = Connector Length (See BFM™ Flexible Connector Sheet)

Note: 1. The stainless steel spigots (flanges) have a tail 52mm (2") long. These can be easily cut down or cut on an angle to suit your existing pipework, see installation instructions for more information.

- 2. It is important to weld the spigots onto your pipework with the length of the flexible connector in mind. Standard length flexible connectors will be stocked and hence will be more readily available, and less expensive than non standard lengths.
- 3. For applications where there is a possibility for static build up, e.g. wood dust, flour, milk powder etc., we recommend using a static dissipative wire (strip), connecting the two BFM™Spigots together.

BFM® FLEXIBLE CONNECTOR

Patents and Registered Designs Applied For © 2006 All rights reserved





Illustrated BFM™ Connector manufactured using 040 Seeflex material (Clear Urethane)



Ø (Diameter)	Length (CL)
100	150
125	150
150	150
200	200
250	200
300	200
350	200
400	200
450	200
500	200
550	200
600	200
650	200

Read this sheet in conjunction with the BFM® Spigots page

Contact BFM Global Ltd for full range of Fabrics available

BFM Global Ltd

PO Box 66-087
Beach Haven, Auckland 0749, New Zealand
Email: sales@BFMfitting.com
www.BFMfitting.com

